

Informações sobre o Queclink GV300

Porta: 6004

Tipo de equipamento:

Configuração inicial:

Restaurar as configurações de fábrica

AT+GTRTO=gv300,4,,,,,FFFF\$

Configurar o fuso horario

AT+GTTMA=gv300,+,0,0,0,,,,,FFFF\$

Configurar APN

AT+GTBSI=gv300,apn,login,senha,,,,,FFFF\$

Cada servidor possui seu próprio DNS. Certifique-se de usar o comando correspondente ao seu servidor específico

Comando para conexão do rastreador com a plataforma - Servidor AL

AT+GTSRI=gv300,4,,2,ese.mine.nu,6004,,,0,0,0,1,,FFFF\$

Comando para conexão do rastreador com a plataforma - Servidor SP

AT+GTSRI=gv300,4,,2,dns.mine.nu,6004,,,0,0,0,1,,FFFF\$

Comando para conexão do rastreador com a plataforma - Servidor SC

AT+GTSRI=gv300,4,,2,sc.mine.nu,6004,,,,0,0,0,1,,,FFFF\$

Configurar tempo de transmissão

Comando 5: AT+GTFRI=gv300,1,0,,0,0000,0000,,20,200,1000,,20,3300,,,,FFFF\$

Configurar bateria externa

AT+GTEPS=gv300,2,1000,28000,2,3,0,0,0,0,1,30,30,,FFFF\$

Configurações globais

AT+GTCFG=gv300,gv300,,1,0,,,3F,2,,1F2F,1,1,1,120,2,1,1,1,1F,0,FFFF\$

Requisitar posição

AT+GTRTO=gv300,1,,0,,,FFFF\$

Demais comandos

Reiniciar o equipamento

AT+GTRTO=gv300,3,,,,,FFFF\$

Habilitar odometro

AT+GTHMC=gv300,1,00000:00:00,,,,,,,FFFF\$

Limpar memória

AT+GTRTO=gv300,D,,,,,FFFF\$

Requisitar posição do GPS

AT+GTRTO=gv300,0,,0,,,FFFF\$

Status do GPRS

AT+GTRTO=gv300,7,,0,,,FFFF\$

Ativar detecção de Jamming

AT+GTJDC=gv300,2,25,,5,10,10,,0,0,0,0,,FFFF\$

Desativar detecção de Jamming

AT+GTJDC=gv300,0,25,,5,10,10,,0,0,0,0,,FFFF\$

Bloqueio

AT+GTOUT=gv300,1,0,0,0,0,0,,,,0,,,,,FFFF\$

Desbloqueio

AT+GTOUT=gv300,0,0,0,0,0,0,,,,0,,,,,FFFF\$

Revision #10

Created 26 March 2024 11:07:11 by Smartgps

Updated 27 January 2025 13:12:53 by Smartgps