

# QUECLINK GV57

☐☐ Tecnologia - 2G

- [Informações sobre o Queclink GV57](#)

# Informações sobre o Queclink GV57

**Porta:** 6004

**Tipo de equipamento:** Básico

---

## Configuração inicial:

### Configurar APN

AT+GTBSI=gv57,apn,login,senha,,,,,FFFF\$

Cada servidor possui seu próprio DNS. Certifique-se de usar o comando correspondente ao seu servidor específico

### Comando para conexão do rastreador com a plataforma - Servidor AL

AT+GTSRI=gv57,1,,1,ese.mine.nu,6004,0.0.0.0,0,,0,0,0,0,,,FFFF\$

### Comando para conexão do rastreador com a plataforma - Servidor SP

AT+GTSRI=gv57,1,,1,dns.mine.nu,6004,0.0.0.0,0,,0,0,0,0,,,FFFF\$

### Comando para conexão do rastreador com a plataforma - Servidor SC

AT+GTSRI=gv57,1,,1,sc.mine.nu,6004,0.0.0.0,0,,0,0,0,0,,,FFFF\$

### Configurar tempo de transmissão

AT+GTFRI=gv57,1,0,,0,0000,0000,,60,1000,1000,,0,3600,,,,,FFFF\$

### Reiniciar equipamento

AT+GTRTO=gv57,3,,,,,FFFF\$

---

## Demais comandos:

### Configuração global

AT+GTCFG=gv57,gv57,gv57,1,0,,,37,2,,180C,,2,0,86400,0,,,1,15,5,0,FFFF\$

### Bloqueio

AT+GTOUT=gv57,1,0,0,,,1,,,,,FFFF\$

### Desbloqueio

AT+GTOUT=gv57,0,0,0,,,1,,,,,FFFF\$

### Configuração de bateria externa

AT+GTEPS=gv57,2,1000,28000,2,3,0,0,0,0,1,30,30,,FFFF\$

### Requisitar posição

AT+GTRTO=gv57,1,,0,,,FFFF\$

### Limpar memória buffer

AT+GTRTO=gv57,D,,0,,,FFFF\$

### Requisitar APN, IP e PORTA

AT+GTRTO=gv57,2,00000000000000001,3,,,FFFF\$

### Requisitar latitude e longitude

AT+GTRTO=gv57,1,,3,,,FFFF\$

### Consultar ICCID

AT+GTRTO=gv57,6,,3,,,FFFF\$

### Requisitar versão do firmware do equipamento

AT+GTRTO=gv57,8,,3,,,FFFF\$

### Consulta nivel de sinal GSM

AT+GTRTO=gv57,7,,3,,,FFFF\$

## **Restaurar as configurações de fábrica**

AT+GTRTO=gv57,4,,,,,,FFFF\$

## **Ativar o modo low sleep**

AT+GTCFG=gv57,gv57,gv57,,,,,2,,,,,,,,,FFFF\$

## **Ativar o modo deep sleep**

AT+GTCFG=gv57,gv57,gv57,,,,,1,,,,,,,,,FFFF\$

## **Desativa o modo deep sleep**

AT+GTCFG=gv57,gv57,gv57,,,,,0,,,,,,,,,FFFF\$

## **Habilita odometro**

AT+GTCFG=gv57,gv57,gv57,1,0,,,,,,,,,FFFF\$

## **Desabilita odometro**

AT+GTCFG=gv57,gv57,gv57,1,0,,,,,,,,,FFFF\$

## **Seta o valor do odometro**

AT+GTCFG=gv57,gv57,gv57,1,X,,,,,,,,,FFFF\$

## **Define o valor do horimetro (HHHH:MM:SS)**

AT+GTHMC=gv57,1,00000:00:00,,,,,,FFFF\$

## **Desabilita horimetro**

AT+GTHMC=gv57,0,,,,,,FFFF\$

## **Reinicio automatico, todo dia às 23hrs**

AT+GTDG=gv57,1,60,1,0200,,1,0,,60,60,30,FFFF\$

## **Configura a lógica de informações no pacote**

AT+GTPDS=gv57,1,278,,,,,,FFFF\$

## **Configuração de reboques para carros e motos**

AT+GTTOW=gv57,1,5,2,600,0,0,0,0,2,3,2,,,,,,,,,FFFF\$

## **Habilitar configuração de excesso de velocidade**

AT+GTSPD=gv57,1,**100,120**,60,300,0,0,0,0,,,,,,,,,FFFF\$

## **Desabilitar configuração de excesso de velocidade**

AT+GTSPD=gv57,0,0,0,60,300,0,0,0,0,,,,,,,,,FFFF\$

## **Habilitar configuração de motor ocioso**

AT+GTIDL=gv57,1,5,5,100,,,0,0,0,0,,,,,FFFF\$

## **Desabilitar configuração de motor ocioso**

AT+GTIDL=gv57,0,5,5,100,,,0,0,0,0,,,,,FFFF\$

## **Configuração de comportamento de motorista**

AT+GTHBM=gv57,1,,,100,36,23,,60,36,23,,,36,23,,0,0,0,0,,,,,FFFF\$

## **Habilitar detecção de Jamming**

AT+GTJDC=gv57,1,29,,10,90,60,,0,0,0,0,,FFFF\$

## **Desabilitar detecção de Jamming**

AT+GTJDC=gv57,0,29,,10,90,60,,0,0,0,0,,FFFF\$